Coverage Benefits

- **Rental reimbursement:** up to \$35 per day for 5 days (or 10 days for a parts delay) from day one.
- 24-hour emergency roadside assistance: up to \$100 per occurrence. Includes towing, battery jump start, fluid delivery, flat tire assistance and lock-out service (Limited to towing for residents of KY).
- Travel expense reimbursement: up to \$500 for lodging, food and rental expense when a covered breakdown or collision occurs more than 100 miles from home (Not available to residents of KY, NY or TX).
- Good at any authorized repair facility in the U.S. or Canada
- No out of pocket expense (except for any deductible): the covered repair is paid by the plan directly to the repair facility.
- **Transferable:** if you sell your vehicle privately, the coverage can be transferred (for an administrative fee), adding resale value and appeal.
- Cancelable: receive a full refund within the first 60 days (if the agreement has not been used) or a pro-rated refund thereafter less an administrative fee.

Additional Benefits

- Lock-in repair costs: Mechanical Repair Coverage (MRC) helps you to limit your cost of unexpected covered breakdowns to the MRC price, plus any applicable deductible.
- Knowing repairs are covered can help your peace of mind: even if your vehicle does not have a covered breakdown during the MRC's term, the purchase of MRC was still a wise decision.
- Help reduce risk: remember, unexpected breakdowns can negatively impact your family's budget. MRC can help alleviate some of these risks.



Mechanical Repair Coverage

Made available by your Credit Union and CUNA Mutual Group

Be sure to read the Vehicle Service Contract or Insurance Policy which will explain the exact terms, conditions, and exclusions of this voluntary product. Coverage will vary by state. MEMBER'S CHOICE® Mechanical Repair Coverage is administered by Consumer Program Administrators, Inc. in all states except AK and CA, where coverage is administered by Virginia Surety Company, Inc., in WA, where coverage is administered by Automotive Warranty Services, Inc., in FL, LA, OK and WI, where coverage is administered by Automotive Warranty Services of Florida, Inc. (Florida License #60023) and in AZ, where the Obligor and Administrator is Consumer Program Administrators, Inc., all located at 175 West Jackson Blvd., Chicago Illinois 60604, 1-800-752-6265. This coverage is made available to you by CUNA Mutual Insurance Agency, Inc. In those states where MEMBER'S CHOICE[®] Mechanical Repair Coverage is offered as insurance (form MCCU-001-MBI) it is underwritten by Virginia Surety Company, Inc.


MEMBER'S CHOICE

MECHANICAL REPAIR COVERAGE

Help protect your vehicle.

FACT #1

As your vehicle gets older, the risk and cost of repairs increases



FACT #2

Repairs can be expensive

| Engine | \$8,050 |
|------------------------|---------|
| Automatic Transmission | \$5,575 |
| Steering Gear | \$1,805 |
| Timing Chain | \$1,735 |
| A/C Compressor | \$1,145 |
| Engine Control Module | \$1,000 |
| Alternator | \$915 |
| Fuel-Pump | \$845 |
| Starter | \$720 |
| Control Arms | \$605 |
| Brake Calipers | \$575 |

The repair costs shown above are for replacement of the components as listed and are for illustrative purposes only. Actual cost may vary by vehicle year, make and model. Data was compiled using manufacturer suggested retail pricing and labor requirements for the specific components as recorded by a nationally recognized labor time publication for a representative sample of 2013 Asian. Domestic and European vehicles.

PLATINUM PLAN

We will remedy any covered breakdown of your vehicle except items listed under the section titled "What this service contract/policy does not cover."

ADDITIONAL PARTS⁺ COVERED BY PLATINUM:

HIGH TECH

+ Factory installed.

Automatic leveling system, cruise control actuator and module, electronic instrument panel control module, electronic stability control system, electronic traction control system, GPS/navigation system and antenna assembly, heated seat element and cooling seat components, rollover protection system. All gauges, sensors and relays.

ENTERTAINMENT SYSTEM

Antenna assembly, compact disc player/changer, DVD player and monitor, graphic equalizer, radio and speakers, satellite radio, telephone prewire/Bluetooth connectivity.

HYBRID COMPONENTS

Combination meter, electronic control module/unit, hybrid vehicle engine control unit (ECU), inverter assembly with converter.

SAFETY AND SECURITY

Gear sets

Shift forks

Heads up display, night vision system, OnStar® system, remote keyless entry transmitter and receiver module, tailgate and hatchback actuators, theft alarm system, tire pressure monitoring system.

• Bearings

Bushings

· Seals and

gaskets

· Seals and

aaskets

Fasteners for

listed above

the components

Fasteners for

listed above.

Electronic

and vacuum

engagement

components

the components

CONVENIENCE

Auxiliary power point, buzzer/chime (headlamps on, key in ignition), cigarette lighter, clock, compass, electrical or mechanical gas cover and trunk releases, glove box lamp (excluding bulb), headlight wiper motor transmission, illuminated entry lamp (excluding bulb), illuminated vanity mirrors, memory seat system, trip/mileage computer, trunk lamp (excluding bulb), volt/amp gauge, wiper motor transmission.

MISCELLANEOUS

Blend door motors, blower motor resistor (regulates fan speed), door hinges, mechanical seat adjustment, outside mirror remote adjustors, rear hatch or hood struts, rear suspension and steering components, weather strips.

AND MORE!

- system
- Power seat motor(s) and transmission(s) Power window motor(s) and power
- · Power door lock actuator(s)
- Digital and analog instrument
- display(s)

SILVER PLAN Silver Plan covers components listed below.*

| I. LINGINE |
|------------|
|------------|

| GASOLINE ENGINE Cylinder block and all internal lubricated parts Crankshaft Rod and main bearings Cam bearings Expansion (freeze) plugs Connecting rods Wrist pins Pistons Piston rings Camshaft Cam tower Lifters Cylinder head Valves and guides Valve springs Rocker arms (cam followers) | Pushrods Timing chain housing (cover) Timing chain and sprockets Timing belt and pulleys Timing belt tensioner Intake and exhaust manifolds Flywheel Balance shafts Harmonic balancer and retainer bolt Crankshaft pulley Valve covers Oil pan Oil pump and pressure relief valve | Engine oil cooler hoses Oil filter adapter/ housing Engine oil sending unit Engine mounts Water pump Temperature sending unit Thermostat and housing Fuel supply pump Vacuum pump Dipstick and tube Seals and gaskets Fasteners for the components listed above |
|--|---|--|
| TURBOCHARGED/SU ROTARY/DIESEL/ENH | ANCED ENGINES | |
| All of the above | Waste gate | Clutch and pulley |

| All of the above listed parts or equivalent Turbocharger | Waste gate controller Intercooler Hard lines | Clutch and pulley Bypass valve Injection pump Lines and nozzles |
|---|--|--|
| , | Compressor | • Seals and gaskets |

2. TRANSMISSION

| AUTOMATIC | | | |
|--|--|--|---|
| Case and all internal lubricated parts Oil pump Valve body Torque converter Vacuum modulator | Governor Main shaft Clutches Bands Drums Gear sets Bearings Bushings Sealing rings | TV cable Solenoids Electronic shift control unit Transmission mounts Cooler hoses and hard lines | Cooler Dipstick and tube Seals and gaskets Fasteners for the components listed above |

| STANDARD |
|------------------------------|
| Case and |
| all internal |

| lubricated parts • Main shaft | Synchronizers |
|----------------------------------|-------------------------------|
| TRANSFER CASE | - (4X4 VEHICLES) |
| Case and | Chain and |

lubricated parts

```
all internal
                        sprockets
 lubricated parts
                      • Bearings

    Main shaft
```

```
    Bushings

    Gear sets

                         • Mounts
```

3. FRONT WHEEL DRIVE

| Final drive housing and all internal parts Carrier case Gear sets Chain and sprockets Bearings | Bushings Axle shafts Universal joints Front hub bearings Rear hub bearings | Locking hub assemblies (4X4) Drive shaft support Seals and gaskets Fasteners for the components listed above |
|--|--|---|
|--|--|---|

4. REAR WHEEL DRIVE

| Drive axle housing and | • Bushings | Universal joints |
|-------------------------|--|---|
| all internal lubricated | Limited slip clutch pack | Drive shaft support |
| parts | Axle shafts | Seals and gaskets |
| Carrier case | Front hub bearings | Fasteners for the |
| Gear sets | Rear hub bearings | components |
| Bearings | Propeller shafts | listed above |

5. STEERING (DOES NOT INCLUDE "REAR WHEEL STEERING" COMPONENTS)

| Housing/case and all internal lubricated parts Rack and pinion equipped valve assembly Sector shaft Rack mounts and cushions Inner rod ends and bellows boots | Speed sensor or steering gear equipped pitman shaft and valve assembly Sealing rings Bearings Bushings Pitman arm Center link Tie rods | Idler arm Power steering pump and pulley Electric power steering motor Fluid reservoir Pressure and return hoses Cooler and hard lines Power cylinder assembly | Steering main and intermediate shafts Coupling Seals and gaskets Fasteners for the components listed above |
|---|--|--|---|

| 6. | F | R | 0 | Ν | Т | S | U | S | Ρ | Ε | N | IS | 0 | N |
|----|---|---|---|---|---|---|---|---|---|---|---|----|---|---|
| | | | | | | | | | | | | | | |

| 6. FRONT SUSPEN | SION | | |
|---|--|--|---|
| Upper and lower control arms Bump stop cushions Control arm shafts Torsion bar mounts and bushings Upper and lower ball joints Dustboots Steering knuckle (spindle) 7. BRAKES | | Wheel bearings and seals Stabilizer shaft Stabilizer linkage mounts and bushings Strut rods and bushings King pins Seals and gaskets Fasteners for the components listed above | |
| cylinder calip • Assist booster • Wheel actu- cylinders • Harr • Combination valve • Bact | brake bers (and caliper lators) d lines fittings king plates | Springs Clips and retainers Self-adjusters Parking brake linkage and cables | - |
| 8. ELECTRICAL Alternator Voltage regulator Front and rear windsh motors and delay con Starter motor and drivities Starter solenoid Wiring harnesses Manually operated sw (specifically turn signation dimmer and wiper swites) Engine management of | troller ve itches al, headlight tches) control unit | (ignition, bra neutral safet Electronic fu (including all output/contr EGR valve, re injection syst Electronic igi Distributor all | y switch) el injection system input/sensors & ol units, except :lated to the fuel iem) nition module |
| Compressor and mounting brackets Clutch and pulley Condenser Evaporator Orifice tube Accumulator Temperature control | High/lov cutoff sy | witches w pressure e cycling ature | Gaskets Fasteners for the components listed above Freon-refrigerant if necessary in conjunction with the repair of the components |

control head

• O-ring seals

programmer

Thermostat

the components

listed above

GOLD PLAN

ALL SILVER PLAN COMPONENTS PLUS THESE ADDITIONAL ITEMS*:

Anti-lock brake

- regulator(s)
- Low fuel sensor

- Low coolant sensor
- · Low oil sensor
- Electronic rear view mirror motor(s)
- Headlight door motor(s)
- Heated back glass
- Windshield wiper washer pump(s)
- Heater-A/C blower motor
- Heater core assembly

- Heater control valve
- Radiator
- Radiator fan and clutch
- Radiator fan motor including fan blade
- Temperature sensor and relay
- Fuel tank and hard lines
- Fuel tank sending unit
- · Power sun roof motor
- Convertible top motor · Constant velocity joints
- · Horn assembly

FACT #3

MEMBER'S CHOICE® Mechanical Repair Coverage (MRC) pays for the cost of covered repairs less any deductible



WHAT THIS SERVICE CONTRACT/POLICY DOES NOT COVER

- Normal maintenance services and parts. Examples: batteries, belts, brake pads, EGR valve, engine tune-up, exhaust, filters, fluids, friction clutch, hoses, hybrid batteries, lubricants, refrigerants, rotors or drums, shock absorbers, shoes, suspension alignment, wheels, wiper blades, etc.
- Abuse, misuse and lack of customary maintenance.

- Body structure and parts, trim, moldings, glass, light bulbs, upholstery, paint, etc.
- Aftermarket equipment, components, systems or accessories not installed by the manufacturer.
- Costs incurred to improve operating performance as result of normal wear and tear where a failure has not occurred.

*Components not listed are not covered.

**Not every deductible available on all MRC Plans or Terms.